

## TECHNICAL DATA SHEET

**1. TRADE NAME: PHERO-SI V ANTHRENUS VERBASCI**

Pheromone dispenser to be introduced in a trap for the monitoring of *Anthrenus verbasci* (varied carpet beetle).

Monitoring device for the IPM application complying with UNI EN 16636:2015 Regulation, that must be applied to control regularly the pests' presence in a specific place for a defined time.

**2. PRODUCT CODE: P-01173**

**3. PICTURE:**



**4. TECHNICAL SPECIFICATIONS:**

Phero-Si V *Anthrenus verbasci* is a monitoring device studied to release the sexual pheromone, whose aim is to attract the male of the indicated species. It must be used inside a trap, so that the pheromone action allows the pest monitoring.

**It is composed of:**

- Polyethylene vial;
  - Sexual pheromone;
- and it is packed in laminated film and cardboard skilket.

**Measures:**

- Height: 44 mm
- Maximum internal diameter: 4 mm
- Maximum external diameter: 6 mm
- Maximum internal volume: 0,5 ml

**Colour:** as in the picture

InPEST products could undergo necessary or opportune technical changes, at any given time, without prior written notice to customers.

## TECHNICAL DATA SHEET

### 5. HOW TO USE:

Place the Phero-Si V *Anthrenus verbasci* inside Multitrap (P-04042), Anobiidi Trap (P-04017), Store Trap (P-04028) or Easy Trap (P-04078). We suggest you to place the trap at a height of 1.80-2 m preferably near a light source, like a window.

These traps must be used in homes, museums, warehouses or in places where wool, jerseys, furs, blankets, carpets, and other fabrics or garments of animal origin are produced, processed or stored, and therefore contain keratin.

We suggest you to give a number to each trap and indicate its placement in the monitored area plan, in order to facilitate the check during the periodic monitoring.

**Note:** the polyethylene vial must not be opened. The vial gradually releases the pheromone through its walls and lid. Any accidental opening does not compromise its effectiveness.

We even suggest the use of gloves every time the pheromone is handled. The eventual smell of smoke or other smells on hands could undermine the product efficacy.

**Distance from the traps:** 200 m<sup>2</sup>.

**Suggested monitoring period:** all the year-long.

**Suggested frequency of the controls:** weekly, change the pheromone dispenser after two months.

**Storage conditions:** in a cool and dry room, temperature below 25°C and R.H. below 55%.  
If well stored (intact packaging), the product shelf life is 3 years. From the pack opening, the pheromone lasts 60 days.

### 6. PACKAGING AND SPARE PARTS:

- Skillet: 15 pcs (sales unit), packed in laminated film (n.3 pieces per strip, for a total of 5 packs per skillet).

### 7. DISPOSAL CONSIDERATIONS:

Waste disposal should be in accordance with existing Community, National and local regulations.