

## TECHNICAL DATA SHEET

### 1. TRADE NAME: **PHERO-SI PATCH CLOTHES BLUE**

Pheromone dispenser to be introduced in a trap for the monitoring of *Tineola bisselliella* and *Tinea pellionella*.

Monitoring device for the IPM application complying with UNI EN 16636:2015 Regulation, that must be applied to control regularly the pests' presence in a specific place for a defined time.

### 2. PRODUCT CODE: **P-16002**

### 3. PICTURE:



### 4. TECHNICAL SPECIFICATIONS:

The Phero-Si Patch Clothes Blue is a monitoring device studied to release gradually the sexual pheromone, whose aim is to attract the male of *Tineola bisselliella* and *Tinea pellionella*. It must be used inside a trap, so that the pheromone action allows the pest monitoring.

#### **It is composed of:**

- Optimized laminated tissue for the gradual release during the time;
- Adhesive;
- Sexual pheromone;

and it is packed in laminated film and cardboard skillet.

#### **Measures:**

- Length: 33 mm
- Height: 21 mm

**Colour:** As in the picture

InPEST products could undergo necessary or opportune technical changes, at any given time, without prior written notice to customers.

## TECHNICAL DATA SHEET

### 5. HOW TO USE:

Place the Phero-Si Patch Clothes Blue for *Tineola bisselliella* and *Tinea pellionella* inside Multitrap (P-04042), Store Trap (P-04028) and glueboards. These traps must be placed at maximum 1.8-2 m height.

These traps must be used inside those places where wool, sweaters, furs, blankets, carpets and other textiles or clothes (animal origin, so with keratin) are stored or processed.

We suggest you to give a number to each trap and indicate its placement in the monitored area plan, in order to facilitate the check during the periodic monitoring.

We even suggest the use of gloves every time the pheromone is handled. The eventual smell of smoke or other smells on hands could undermine the product efficacy.

**Distance from the traps:** 200 m<sup>2</sup>.

**Suggested monitoring period:** all the yearlong.

**Suggested frequency of the controls:** weekly, change the pheromone dispenser after two months.

**Storage conditions:** in a cool and dry room, temperature below 25°C and R.H. below 55%.

If well stored (intact packaging), the product shelf life is 3 years. From the pack opening, the pheromone lasts 90 days.

### 6. PACKAGING AND SPARE PARTS:

- 1 pc per pack;
- Skillet: 50 pcs (sales unit).

### 7. DISPOSAL CONSIDERATIONS:

Waste disposal should be in accordance with existing Community, National and local regulations.