

TECHNICAL DATA SHEET

1. TRADE NAME: **MASS TRAP**

Monitoring device to detect the presence of food moths (*Plodia interpunctella*, *Ephestia kuehniella*, *Ephestia elutella*, *Cadra cautella*, *Cadra figulilella* e *Nemapogon granellus*) to be activated with the specific pheromone dispenser.

Monitoring device for the IPM application complying with UNI EN 16636:2015 Regulation, that must be applied to control regularly the pests' presence in a specific place for a defined time.

2. PRODUCT CODE: **P-25003**

3. PICTURE:



4. TECHNICAL SPECIFICATIONS:

Mass® Trap is a monitoring device (funnel trap with a collecting bag). The trap must be activated with pheromone dispenser specific for the target pest (to buy separately).

It is composed of:

- 1 funnel trap for the entrance of the pest
- 1 bag for the insect collection
- 1 wire for trap positioning.

Colour: As in the picture

InPEST products could undergo necessary or opportune technical changes, at any given time, without prior written notice to customers.

5. HOW TO USE:

Place the Mass Trap in the following places:

Inside food industries, storehouses, supermarkets, mills and all those places where it is stocked: wheat, cereals, biscuits, bread, pasta, chocolate, cocoa, candy, dried fruit etc. This trap is particularly suitable in dusty environments such as mills.

TECHNICAL DATA SHEET

It must be placed at 1,8-2 m height.

We suggest you to give a number to each trap and indicate its placement in the monitored area plan, in order to facilitate the check during the periodic monitoring.

Theoretical covered area: 200 m².

Suggested monitoring period: all the yearlong.

Suggested frequency of the controls: weekly. Change the pheromone dispenser and or the collecting bag trap after two months (at the latest) or before according to the pest infestation.

Storage conditions: in a cool and dry room, temperature below 25°C and R.H. below 55%.

6. PACKAGING AND SPARE PARTS:

- Mass® Trap (P-25003): 10 pcs of trap body and 30 plastic bags included.

Pheromone dispenser to be used with Mass Trap (to buy separately):

- Phero-Si Food (P-01048): pheromone for *Plodia interpunctella*, *Ephestia kuehniella*, *Ephestia elutella*, *Cadra cautella* and *Cadra figulilella*;
- Phero-Si *Nemapogon granellus* (*Tinea granella*) (P-01003): pheromone for *Nemapogon granellus*.

Pheromone dispensers are also available in the detectable version.

For other flying insect species, which can be found in food industries, and for other attractant typologies, please, contact our commercial department.

Replacement bag:

- 50 pcs of collection bags (P-042071).

Pheromones can be purchased separately.

7. DISPOSAL CONSIDERATIONS:

Waste disposal should be in accordance with existing Community, National and local regulations.